



二. 安装步骤

part list

Number	Component	Quantity
1	Bracket	1
2	M10 Expansion screws	4
3	Copper sleeve	4
4	Lock screws	4
5	Shower assembly	1
6	Water inlet connecting pipe	1

二. 安装步骤

1. Take a copper sleeve to use the lock screws then separate the showerhead assembly and bracket.
2. Dig 4  $\phi 10$  holes on the ceiling according to the dimension of the screws.
3. Use a hammer to thash the 4 screws into 4 holes.
4. Install the bracket on the expansion screws, then use copper sleeve wrench to lock 4 screws.
5. Make sure of the water inlet pipe connected well without leaking before insert the power plug into the socket.
6. Fix the shower assembly on the bracket by turn the locking bolt.